



Field Installation of Grounding Whisker For Swim-Lift[®] Models Lolo, Gallatin and Pintlar

P/N 204219-04

The Grounding Whisker is a grounding contact for the seat pole on the Swim-Lift[®] models Lolo, Gallatin and Pintlar. The seat pole is isolated by an insulator (the internal piston assembly) and is not grounded to the rest of the lifts components. Some building codes require that all metallic components, of equipment located in, and around, swimming pools be bonded to a common bonding (grounding) grid. This Grounding Whisker allow for contact of all metal components of the lift to be bonded to the common bonding (grounding) grid.

Simply remove the pictured mounting bolt and place the Grounding Whisker in place as shown. Re-install the bolt and secure firmly. The Grounding Whisker is now creating the bond between all metallic components of the lift.

